



Bansilal Ramnath Agarwal Charitable Trust's
Vishwakarma Institute of Information
Technology

**Department of
Artificial Intelligence and Data
Science**

Name: Siddhesh Dilip Khairnar

Class: TY

Division: B

Roll No: 372028

Semester: V

Academic Year: 2023-2024

Subject Name & Code: Image Processing: ADUA31205(B)

Title of Assignment: Perform object detection from an image

Date of Performance: 01-11-2023

Date of Submission: 11-11-2023

ASSIGNMENT NO. 8

Name : Siddhesh Dilip Khairnar
PRN no : 22110398
Roll no : 372028

Page No.	
Date	

IP Assignment no 8

Aim: Perform object detection from an image

Learning objective : →

- 1) learn the concept of object detection, which involves identifying & localizing object within image or video frames.
- 2) familiarize with different object detection models, such as faster R-CNN, YOLO & SSD, and select one that suits your needs.
- 3) learn about class prediction for detected objects, often using softmax activation to estimate class probabilities.

Theory : →

Object detection is a computer vision task that involves identifying and locating objects within an image. Here's a high-level overview of the theory & steps involved in performing object detection from an images :

- 1) Data collection :
Gather a dataset of image that contain the object you want to detect. Annotate these images to specify the location of each object with bounding boxes.
- 2) select a Model : →
choose a pre-trained object detection model or design your own. popular models includes faster R-CNN, yolo and SSD (single shot Multi-Box Detector)

3) Preprocessing : -

prepare your input images by resizing, normalizing and augmenting them as needed.

4) Feature Extraction : -

The selected model will use convolution layer to extract features from the input image.

5) Object Localization : -

The model's localization head will predict bounding boxes (coordinates) for each detected object within the image.

6) Object Classification : -

The classification head of the model will predict the class of each detected object. This is often done using a softmax activation function to estimate class probabilities.

7) Non Maximum suppression : -

To eliminate duplicate or overlapping detection, apply non-maximum suppression (NMS) to retain the most confident predictions.

8) Post-processing : -

Translate the model's output into human-readable result by converting coordinates to pixel positions, associating class labels, and confidence score with each detected object.

9) Visualization : -

Draw bounding boxes and labels on the original image to display the detected objects.

10) Evaluation and fine-tuning : →

Evaluating the model's performance using metrics like mAP (mean Average precision). fine tune the ~~message~~ model if necessary to improve detection accuracy.

11) Deployment : →

Deploy the object detection model in your application or system, whether it's for real-time processing or batch processing.

12) Inference : →

Use the trained model to perform object detection on new, ~~the~~ unseen images.

~~Remember~~ :

Conclusion : →

Learn the concept of object detection, which involves identifying and localizing object within image or video frames.

~~For~~
21/12/22

Program Code:

```
import cv2
from matplotlib import pyplot as plt
import os

# Get the full path to the current script
script_path = os.path.dirname(os.path.abspath(__file__))

# Load Haar cascade file for eyes
cascade_path = os.path.join(
    script_path, "C:/Users/asus/Downloads/haarcascade_eye.xml")
stop_data = cv2.CascadeClassifier(cascade_path)

# Check if the cascade classifier is loaded successfully
if stop_data.empty():
    print(f"Error: Unable to load cascade classifier from {cascade_path}")
    exit()

# Opening image
img = cv2.imread("C:/Users/asus/Downloads/Rahul-Gandhi.webp")

# Convert the image to grayscale
img_gray = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)

# Detect eyes
found = stop_data.detectMultiScale(img_gray, minSize=(20, 20))

# Display the original image
plt.figure(figsize=(10, 10))
plt.subplot(1, 2, 1)
plt.title('Original Image')
plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB))

# Display the image with detected eyes
for (x, y, width, height) in found:
    cv2.rectangle(img, (x, y), (x + width, y + height), (0, 255, 0), 5)

plt.subplot(1, 2, 2)
plt.title('Image with Detected Eyes')
plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB))
plt.show()
```

XML LINK: [haar-cascade-files/haarcascade_eye.xml at master · anaustinbeing/haar-cascade-files \(github.com\)](https://github.com/anaustinbeing/haar-cascade-files/blob/master/haar-cascade-files/haarcascade_eye.xml)

Output:

